



PH: 866-972-2731
FAX: 858-643-9060
Sales@VisualEdgeSB.com
www.SlantB.com

Visual Edge Slant Board® Paper Catch Removal and Replacement Instructions



TOOLS REQUIRED

- Drill with ¼" bit
- Flat head screwdriver
- Pliers (Needle Nose Preferred)

ITEMS ENCLOSED

- 1 Set of Instructions
- 1 Metal Paper Catch
- 2 Round Head #8 x 3/8" Bolts
- 2 Hexagonal #8 Nuts
- 2 #8 Lockwashers

REMOVAL INSTRUCTIONS

- 1) On a level stable surface place the Slant Board face down. With the drill and ¼" bit carefully drill out the end of both rivet stems to just below the washer.
- 2) With the pliers grab the outside of the washer and pull both washers off.
- 3) Turn Slant Board over and gently pull the broken paper catch off.
- 4) If there is some resistance removing the paper catch, turn the Slant Board back face down and with the pliers crimp the end of the rivet stem into a point and reattempt pulling the paper catch off.

INSTULATION INSTRUCTIONS

- 1) Align the new metal paper catch with the holes on the front side of the Slant Board.
- 2) Insert the bolts through the paper catch and Slant Board from the front side.
- 3) From the backside of the Slant Board first place the lockwasher onto the bolt, then screw on the nut and tighten with your fingers.
- 4) With the pliers firmly hold the nut on the backside of the Slant Board and with the screwdriver tighten the bolts from the front.

YOUR VISUAL EDGE SLANT BOARD® IS NOW READY TO USE!

IF YOU HAVE ANY QUESTIONS OR DIFFUCULTIES WITH YOUR INSTULATION PLEASE EMAIL US AT SALES@VISUALEDGESB.COM