



PH: 866-972-2731  
FAX: 858-643-9060  
[Sales@VisualEdgeSB.com](mailto:Sales@VisualEdgeSB.com)  
[www.SlantB.com](http://www.SlantB.com)

## Visual Edge Slant Board® Leg Removal and Replacement Instructions



### TOOLS REQUIRED

- Drill with ¼” bit
- Flat head screwdriver
- Pliers (Needle Nose Preferred)

### ITEMS ENCLOSED

- 1 Set of Instructions
- 1 Plastic Leg Mounting Unit
- 1 Plastic Leg
- 1 Rubber Leg End Cap
- 2 Round Head #8 x 5/8” Bolts
- 2 Hexagonal #8 Nuts

### REMOVAL INSTRUCTIONS

- 1) On a level stable surface place the Slant Board face down. With the drill and ¼” bit carefully drill out the end of both rivet stems to just below the washer.
- 2) With the pliers grab the outside of the washer and pull both washers off.
- 3) Grasp the plastic leg-mounting unit and gently pull away from the board.
- 4) If there is some resistance removing the leg-mounting unit, with the pliers crimp the rivet stem into a point and reattempt pulling the leg-mounting unit off.

### INSTULATION INSTRUCTIONS

- 1) Place the plastic leg into the slot on the leg-mounting unit with the spacing peg facing up.
- 2) Turn the two pieces over, placing them on the backside of the Slant Board and align the new leg-mounting unit with the holes on the Slant Board. Hold in place with your hand.
- 3) From the front side of the Slant Board insert the bolts through the holes in the board and leg-mounting unit.
- 4) From the backside of the Slant Board screw on the nut and tighten with your fingers.
- 5) With the pliers firmly hold the nut on the backside of the Slant Board and with the screwdriver tighten the bolts from the front.

**YOUR VISUAL EDGE SLANT BOARD® IS NOW READY TO USE!**

**IF YOU HAVE ANY QUESTIONS OR DIFFUCULTIES WITH YOUR INSTULATION PLEASE EMAIL US AT [SALES@VISUALEDGESB.COM](mailto:SALES@VISUALEDGESB.COM)**