

PH: 858-822-9881 FAX: 334-835-8869 info@visualedgesb.com www.visualedgesb.com

Visual Edge Slant Board® Leg Removal and Replacement Instructions



TOOLS REQUIRED

Drill with ¼" bit
Flat head screwdriver
Pliers (Needle Nose Preferred)

ITEMS ENCLOSED

1 Set of Instructions

1 Plastic Leg Mounting Unit

1 Plastic Leg

1 Rubber Leg End Cap

2 Round Head #8 x 5/8" Bolts

2 Hexagonal #8 Nuts

REMOVAL INSTRUCTIONS

- 1) On a level stable surface place the Slant Board face down. With the drill and ¼" bit carefully drill out the end of both rivet stems to just below the washer.
- 2) With the pliers grab the outside of the washer and pull both washers off.
- 3) Grasp the plastic leg-mounting unit and gently pull away from the board.
- 4) If there is some resistance removing the leg-mounting unit, with the pliers crimp the rivet stem into a point and reattempt pulling the leg-mounting unit off.

INSTULATION INSTRUCTIONS

- 1) Place the plastic leg into the slot on the leg-mounting unit with the spacing peg facing up.
- 2) Turn the two pieces over, placing them on the backside of the Slant Board and align the new leg-mounting unit with the holes on the Slant Board. Hold in place with your hand.
- 3) From the front side of the Slant Board insert the bolts through the holes in the board and leg-mounting unit.
- 4) From the backside of the Slant Board screw on the nut and tighten with your fingers.
- 5) With the pliers firmly hold the nut on the backside of the Slant Board and with the screwdriver tighten the bolts from the front.

YOUR VISUAL EDGE SLANT BOARD® IS NOW READY TO USE!

IF YOU HAVE ANY QUESTIONS OR DIFFUCULTIES WITH YOUR INSTULATION PLEASE EMAIL US AT SALES@VISUALEDGESB.COM